



ENVISAGER EN-5050: Software Upgrade procedure.

Main software upgrade:-


Prepare the EN-5050 receiver: Connect a null modem serial cable in between computer and EN-5050 FTA box. **Change the mode switch located in rear panel to position "A".**



Open "Upgrade_Twin" PC software loader and select the Main software "Envisager_MAIN_RE_29c39RCU.bin"



Press "Next" button on PC loader and Switch ON the EN-5050 FTA from the mains. Follow the PC loader instruction and complete the Main software download.



Once it finished, disconnect the EN-5050 FTA from the mains.

Slave software upgrade:-

Prepare the EN-5050 receiver same as above and change the mode switch located in rear panel to **position "B"**.



Download slave software "Envisager_SLAVE_RE_29cRCU.bin" to EN-5050 FTA with same procedure.



Once slave software download is finished, disconnect serial cable from box.

Change the mode switch in rear panel to **position "N"**



Mode Switch Selections: -

Main Software: - Position A

Slave Software: - Position B

Normal working:- Position N