


Eagle SW Upgrade Procedure

1. SW folder : It needs to locate at same folder.




2. Procedure


1) Click **UpdateD_org** from folder



2) Click [OpenFile] and Open [out_elf_W3A_20110311.s]



3) It will be displayed as follows



4) Click [Update] and Power on the Eagle Dongle

